

WINDING RTD'S

1. THERE ARE QTY-12 RESISTANCE TYPE TEMPERATURE DETECTORS (RTD) INSTALLED IN THE STATOR WINDING (4 PER PHASE). REFER TO NAMEPLATE ATTACHED TO THE MOTOR ADJACENT TO ACCESSORY OUTLET BOX FOR RATING OF THE RTD'S.
2. DETECTORS ARE INSTALLED IN PHASES AS SHOWN.

PHASE	A	B	C
RTD NO.	1, 11, 4, 44	2, 22, 5, 55	3, 33, 6, 66



ACCESSORY LISTING
QTY. 12 - 3 LEAD RTD's

REVISION DESCRIPTION FOR: <b>MISC</b>	SCALE <b>NONE</b>	UNITS <b>IN</b>	TITLE <b>CUSTOMER CONNECTION DIAGRAM</b>		<b>NIDEC MOTOR CORPORATION</b>
<b>STL0211 - UPDATED FORMAT.</b>	TOLERANCES ON DIMENSIONS (UNLESS OTHERWISE SPECIFIED)		ISSUED BY <b>R. KING</b>		
MATERIAL: <b>---</b>	<u>INCHES</u>	<u>mm</u>	APPROVED BY <b>C. CADE</b>	REV <b>D</b>	SHEET NUMBER <b>1 OF 1</b>
MUST BE COMPLIANT TO RoHS DIRECTIVE EU 2002/95/IEC AND REGULATION EC 1907/2006 (REACH) AS AMENDED	ANGLES $X^\circ = \pm 1^\circ$		CODE	DWG NO. <b>0411374</b>	DWG SIZE <b>A</b>